

**Supply List:**

- 27" x 22" main body fabric
- Fat ¼ of pocket fabric
- Fat ¼ of binding fabric
- 27" x 22" of backing fabric
- 27" x 22" piece of batting
- 3" x 22" piece of batting
- 4¾" x 22" piece of batting

A great beginning machine quilting project!

**Note:** The 22" is approximate, it's ½ the width of the fabric

**Cutting:**


- From the pocket fabric, cut:
  - 2 - 4¾" x 22" strips for large pocket
  - 2 - 3" x 22" strips for small pocket
  - 2 - 1" x 22" strips for ties
- From the binding fabric, cut:
  - 7 - 2¼" x 22" strips

**Quilting:**

Sandwich and quilt the 27" x 22" of main body fabric, batting and backing fabric. I quilted a diagonal grid pattern. Measure your machine from the front over the top and to the back and note this measurement. Trim your piece to the measurement you noted and approximately 21". I trimmed mine to 23" x 21". Set aside.

**Ties:**

Press a 1" x 22" strip of fabric for the ties in half lengthwise with wrong sides together. Fold and press in half again. Stitch down the center. Cut in half on the diagonal to make two ties. Repeat to make two more ties for a total of four.




Make 4

**Pockets:**

With wrong sides in, sandwich the 4¾" x 22" strip of batting between the 2 pieces of 4¾" x 22" strips of pocket fabric. Repeat for the small pocket, 3" x 22" pieces and the corresponding batting piece.

Optional: Quilt the pockets. If you do not quilt the pockets, the topstitching to create separate pockets will hold the batting in place. I did not quilt the pockets.

Bind one long end of both the small and large pockets using the 2¼" x 22" strips of binding fabric. Place the small pocket on top of the large pocket, raw edges meeting to make the pocket unit. Create smaller pockets by topstitching vertical lines on the small pocket.



Stitch vertical lines on the smaller pocket to create smaller pockets

**Putting it all together:**

Place the pocket unit on one end of the main body, raw edges matching. Stitch the pocket unit to the main body fabric using a scant ¼" seam. Mark in about 7" from both sides and stitch more vertical lines to make additional pockets. Place the ties about 6½" from both ends on both sides. Stitch in place using a scant ¼" seam.



Sew the remaining 2¼" x 22" strips of binding fabric together on the diagonal. Bind the entire cover and around the edges. Cover your machine and/or use it as a pad and enjoy!!



Open Gate

[opengatequilts.com](http://opengatequilts.com)

